



IP-MODULE

The default configuration for an IP-Module with v2.10.5542 firmware and above is DHCP Enabled and smart phone App Enabled. Configuration of the IP-Module is only required for CID Monitoring Station use.




How to change your PC's IP Address



IP Module Finder Software

If your PC is connected to the same Network as the IP-Module you can use our IP Tool to find the device.

Download from:
www.aap.co.nz/iptool



Accessing the IP-Module to adjust Configuration.


Open your web browser: Internet Explorer 9 & above, Safari, Fire-Fox or Google Chrome (*Explorer 6,7 & 8 not supported*)

In the browser type in the IP-Modules Address **192.168.1.100** then press **Enter**




IP-Module Configuration


1. From the IP-Modules Home page Click Login




2. Click in the Password box and type in the System Password **000000** then press **Enter** (000000 is the default system password)



3. By Default **DHCP** is Enabled This allow the IP-Module to be assigned and IP address and gateway by the network equipment. If you wish to configure the network setup manually un-tick this box and enter your details in the appropriate fields.



4. Select **Mobile APP** tab




5. By Default the **Mobile App** feature is Enabled. If you don't wish to use this feature un-tick this box.

If there is unwanted users listed on the App, changing this number will shut down that site, preventing all user access. A new site must then be added on your App, using this new Serial number.

CID Monitor Station Setup

Contact your monitoring station for the information required below.

6. Select **CID Settings** tab



7. Tick Enable CID Reporting

8. Enter your 4 digit Account Code

9. Fill in the Monitor Station IP Address/ Web Address, port number and CID Polling Code

10. Select the IP Protocol

11. Set the Polling time

12. Now click **Save & Restart**

Example Information Only.

ALARM SYSTEM SETUP FOR REPORTING

The Alarm System must also be programmed for reporting

You will need to programmed in:

1. A telephone number (this can be anything from 1-999999999)
2. That telephone number must be set to Contact ID reporting format.
3. The dialler must be enabled.

If you are using an **Elite S/S-Lite** here are the Programming Addresses:

1. **P 181 E 1 E** (put in a phone number 123) **E**
2. **P 182 E 1 E** turn option **1** ON and **E**
3. **P 175 E 1 E** turn option **1** ON only and **E**

ALARM SETUP FOR REMOTE CONTROL (ELITE S/S-LITE ONLY)

The Elite-S/S-Lite has upto 8 outputs that can be controlled via the Elite Control App. Each output must be setup individually if you wish to control them remotely. These 3 steps below need to be done in Installer Program Mode of the Elite-S/S-Lite.

1. Output Options

The first thing you need to setup is giving permission for that output to be controlled by keypads. This is done at address 34. In Installer mode press **<PROGRAM> <34> <ENTER>** then choose the output **<1-8>** and **<ENTER>**, now turn ON option **<7>** and **<ENTER>**.

i.e. **P 34 E 4 E 7 E** (output 4 can is now allowed to be controlled).

↑ address
↑ output number
↑ option to be turned On

Note: Outputs 1 & 2 are setup by default to be sirens and would not normally want to be controlled via the virtual terminal.

2. Keypad to Output Control Mapping

The keypad number of the IP-Module (fixed to No.8) must now be assigned to the output/outputs you wish to control. This is done at address 83. In Installer mode press **<PROGRAM> <83> <ENTER>** then select the keypad number **<8>** and **<ENTER>**, now choose the output/s **<1-8>** and **<ENTER>**.

i.e. **P 83 E 8 E 4 E** (the App can now control output 4).

↑ address
↑ keypad number of IP-Module
↑ output number

3. Output Reset Times


The output reset time will normally already be set, according to the device it controls. Because of the delays involved in IP-Control, if an output has a reset time of less than 2 second you will not see a triggered response in the Virtual Terminal. In Installer Mode press **<PROGRAM> <40> <ENTER>** then the output you wish to change **<1-8>** and **<ENTER>** now put in the new reset time **<0-9999>** and **<ENTER>**.

i.e. **P 40 E 4 E 2 E** (output 4 reset time is now 2 seconds, recommend for garage door control).

↑ address
↑ output number
↑ new time in seconds

OPERATING AND TROUBLE SHOOTING

LED INDICATIONS



BLUE FAST FLASHING 4 flashes every second	Ready	Network detected
BLUE SLOW FLASHING 1 flash every second	Fault	No Network detected
GREEN STEADY	Dialling Out	The alarm panel connect to the Line-in terminals has Looped the line and is attempting to dial out.
BLUE STEADY	Monitoring Fail	Unable to connect to the Monitoring Station.
RED STEADY	APP Server Fail	The IP-Module has failed to connect to the network router and be assigned an IP address/gateway
RED FLASHING	ULD Operating	Remote Upload/Download software is accessing the Panel through the IP-Module
ALL FLASHING	DEFAULT	There is no programming saved in the module
LED 3 & 4 Alternating	Setup Error	Neither CID or Mobile APP reporting is enabled

Getting Back into Program Mode with DHCP Enabled

Once you have Enabled DHCP and connected the IP-Module to the router a new IP Address will automatically be assigned. This can cause a problem when you try to get back into it's web page to change programming.



Follow these steps to get back into the web page:

1. Power down the IP-Module.
2. Connect the IP-Module directly to your PC/MAC (as shown in diagram 1)
3. Power up the IP-Module.

You will then be able to use the default IP address (192.168.1.100) to get into the setup web page.

Resetting



Warning, performing a Reset will wipe all programming fields and return the IP-Module back to factory default. This includes returning it's IP address back to (192.168.1.100).

To reset simply press and hold the reset button  until the LED turns Off. (about 5 second) 

These 4 LED's will start flashing, when you press the reset button

Optional Wiring.

By wiring as shown here the IP-MODULE can reboot the router, should there be a connection problem.



To utilise the Router Reboot feature, you will need to enable it through the IP-Modules web page.

Log into the IP-Module. Under **'Network'** there is a box labelled **'Relay Count'** (default **0** = OFF)

This number equals the number of reboot attempts the IP-Module will perform on the Router before giving up and waiting for the connection to automatically recover. (A couple of attempts is all you would normally need).

'Router On Delay' is the time in which the router should have come back online, before another reboot is attempted.

Note: In the event of a power failure your alarm may not be able to report, due to 3rd Party hardware not being battery backed-up.

ARROWHEAD ALARM PRODUCTS Ltd.

1a Emirali Rd,
Silverdale,
Auckland.
Ph. 09 414 0085
Fax. 09 414 0088
www.aap.co.nz
v4.1



Arrowhead
Alarm Products