

### **179.210 Microfoon met ontvanger koppelen.**

Zet beide units uit.

Schakel dan de microfoon in terwijl je kanaal select schakelaar ingedrukt houdt.

Nu zal het display beginnen te knipperen, laat de schakelaar weer los.(Display blijft knipperen)

Schakel de ontvanger in, deze zal een paar keer (4x) knipperen en gaat dan weer uit.

Nu heeft de ontvanger even contact gemaakt met de microfoon.

Schakel de microfoon uit en weer in, nu zou het toestel gepaard moeten zijn.

### **179.210 Mikrofon mit Empfänger koppeln.**

Schalten Sie beide Geräte aus.

Schalten Sie dann das Mikrofon ein, während Sie den Kanalwahlschalter gedrückt halten.

Jetzt beginnt die Anzeige zu blinken, lassen Sie den Schalter wieder los (die Anzeige blinkt weiter).

Schalten Sie den Empfänger ein, er blinkt ein paar Mal (4x) und schaltet sich dann wieder aus.

Jetzt hat der Empfänger kurzzeitig Kontakt mit dem Mikrofon aufgenommen.

Schalten Sie das Mikrofon aus und wieder ein, nun sollte das Gerät gepaart sein.

### **179.210 Pair microphone with receiver.**

Turn off both units.

Then turn on microphone while holding channel select switch.

Now the display will start to flash, release the switch again.(Display will continue to flash).

Turn on the receiver, it will flash a few times (4x) and then turn off.

Now the receiver has briefly made contact with the microphone.

Turn the microphone off and on again, now the unit should be paired.