

To change the melody , use the switch on the side of the unit



If you suffer interference from other units , you can change the channel by fitting the supplied jumpers on the transmitter and setting the switches on the receiver units . See attached photographs

